

## TTN Top Lever Spring Instructions

First unload the shotgun and *make sure you have screwdrivers that fit!*

- Remove the forearm and barrel.
- Remove the side plates.
- Remove the two trigger tang screws (remember which one is which).
- Pull the triggers and unscrew the trigger guard from the frame.
- Remove large screw forward of the trigger guard.
- Remove screw from rear of top tang.
- Move opening lever to the right and remove large screw underneath lever.
- Pull stock off.
- Clamp receiver in padded vise facing down.
- Using needle nose vise-grips, clamp the lever spring (“V”) spring together and remove spring.
- Compress replacement spring and insert the spring tips into the divots (**MAKE SURE THE LONGER LEG OF THE SPRING GOES TO THE OUTSIDE AGAINST THE FRAME**). Depending on the size and depth of the locating divots, you may have to “dress” the spring tips to a point to ensure they seat fully.
- Work the lever a couple of times to ensure the spring stays seated and to give it a “set”.
- While you’re at it and have it open, grease the internal moving parts.
- Reverse steps 8 through 1.